

Water Analysis Meter PCE-CP 10



Water analysis meter PCE-CP 10

Multi-parameter photometer with Bluetooth interface / PC software / Cloud service / Cross-system synchronization of measured values / Up to 5 selectable parameters / For measuring e.g. pH, alkalinity, chlorine, cyanuric acid / storage of measured values

The multi-parameter photometer is a mobile measuring device for liquid analysis. This means that the most varied of measurements can be carried out with the multi-parameter photometer. With this multi-parameter photometer it is possible, for example, to determine alkalinity, chlorine, cyanuric acid or the pH value. In order to carry out a measurement with the multi-parameter photometer, a water sample of 10 ml must be placed in a cuvette. The LED built into the multi-parameter photometer generates a test light in the wavelength ranges of 503 nm, 570 nm and 620 nm. A photodiode now recognizes the value to be measured based on the light transmission of the sample.>

Each measurement is automatically saved by the multi-parameter photometer. The stored measured values can then be read out, for example, via a mobile device via the Bluetooth interface built into the multi-parameter photometer. A free app is available to analyze the measured values from the multi-parameter photometer. It is also possible to establish a Bluetooth connection between the multi-parameter photometer and a computer. Free software is also available for this, with which the measurement data can be analyzed. As another special feature of the multi-parameter photometer, the measurement data can be uploaded to a cloud using both variants and accessed from anywhere. This service for the multi-parameter photometer is also free of charge.

- ▶ Adjustable units: mg / l, ppm
- ▶ Up to 5 selectable parameters
- ▶ Bluetooth connection with app
- ▶ Exchangeable and lockable cuvette
- ▶ 503 nm / 570 nm / 620 nm LED
- ▶ Automatic shutdown when inactive
- ▶ Many different menu languages
- ▶ Light detector: photodiode
- ▶ Cuvette: 36 x ø 21 mm / 3.6 x ø 2.1 cm (10 ml)

Specifications

Alkalinity

Measuring range	0... 30 mg / l
	30... 60 mg / l
	60... 100 mg / l
	100... 200 mg / l

Accuracy	3 mg / l
	7 mg / l
	12 mg / l
	18 mg / l

Resolution	1 mg / l
------------	----------

Chlorine

Measuring range	0.00 ... 2.00 mg / l
	2.00 ... 3.00 mg / l
	3.00 ... 4.00 mg / l
	4.00 ... 8.00 mg / l

Accuracy	0.10 mg / l
	0.23 mg / l
	0.75 mg / l
	1.00 mg / l

Resolution	0.01 mg / l
------------	-------------

Cyanuric acid

Measuring range	0... 15 mg / l
	15... 50 mg / l
	50... 120 mg / l
	120... 160 mg / l

Accuracy	1 mg / l
	5 mg / l
	13 mg / l
	19 mg / l

Resolution	1 mg / l
------------	----------

More information

More product info



Similar products



Subject to change

pH

Measuring range	6.50 ... 8.40 pH
Accuracy	0.11 pH
Resolution	0.01 pH

Further specification

Unit	mg / l, ppm mg / l CaCO ₃ , ppm, mmol / l KS 4.3,
Hardness units	° dH (degree of German hardness), ° e (degree of English hardness / degree Clark), ° f (degree of French hardness)
Calibration	Zero point calibration
Light source	503 nm / 570 nm / 620 nm LED
Light detector	Photodiode
Power supply	4 x 1.5V AA batteries
Dimensions of the cuvette	36 x ø 21 mm / 3.6 x ø 2.1 cm(10ml)
Menu languages	English, German, French, Spanish and Italian
Storage	Automatic storage of measured values and readout
Storage space	256 values
interface	Bluetooth connection with app and PC software
Automatic shutdown	After 300 seconds of inactivity
Operating conditions	5 ... 45°C / 41 ... 113°F, 20 ... 90% RH non-condensing
Storage conditions	5 ... 45°C / 41 ... 113°F, 20 ... 90% RH non-condensing
Dimensions	165 x 95 x 50 mm / 6.5 x 3.7 x 2 in
Weight	230 g / < 1 lb

Subject to change